











Features

- 1 - 2 loop
- XP95 protocol
- Extensive cause and effect capability
- Windows-based, full upload/download PC software package
- 500mA output per loop with highly stable voltage platform, even under mains-failed conditions
- Fully networkable
- Powerful processing and extensive panel and loop I/O capability
- User-friendly controls and a clear, unambiguous screen
- Membrane fascia with tactile switches

Documentation

- [User Manual](#)
- [Installation Manual](#)
- [Programming Guide](#)
- [EA Pro-Line Datasheet](#)
- [Loop Planning Sheet](#)

Part Numbers

Part No	Description	Picture	Download
10-0020	EA Pro-Line 1 Loop		User Manual Installation Manual Datasheet Loop Calculator Programming Software Programming Guide Loop Planning Sheet
10-0022	EA Pro-Line 2 Loop		User Manual Installation Manual Datasheet Loop Calculator Programming Software Programming Guide Loop Planning Sheet
09-0005	Addressable Optical Detector (LPCB Approved)		Datasheet Addressing Guide
09-0006	Addressable Heat Detector - 57° C (LPCB Approved)		Datasheet Addressing Guide
09-0007	Addressable Heat Detector - 90° C (LPCB Approved)		Datasheet Addressing Guide
09-0008	Addressable Optical Detector (Euro Approved)		Datasheet Addressing Guide
09-0009	Addressable Heat Detector (Euro Approved)		Datasheet Addressing Guide
09-0010	Common Base		Datasheet Wiring Guide

09-0013

Addressable Relay Base



[Datasheet](#)
[Wiring Guide](#)

09-0011

Short Circuit Isolator Base



[Datasheet](#)
[Wiring Guide](#)

09-0012

Standalone Short Circuit Isolator (Base + Cover)



[Datasheet](#)
[Wiring Guide](#)

09-0014

Loop Powered Sounder Base



[Datasheet](#)
[Wiring/Setup Guide](#)

09-0016

Addressable Call Point



[Datasheet](#)
[Addressing Guide](#)

09-0015

Addressable Remote LED Indicator



[Picture](#)
[Addressing Guide](#)

09-0028

Addressable Vantage Sounder (100dBA)



[Datasheet](#)
[Addressing Guide](#)

09-0029

Addressable Vantage Sounder/Strobe (100dBA)



[Datasheet](#)
[Addressing Guide](#)

09-0017

Addressable Loop Powered Sounder/Strobe (80dBA)



[Datasheet](#)
[Addressing Guide](#)

09-0018

Addressable Loop Powered Midi Room Sounder (80dBA)



[Datasheet](#)
[Addressing Guide](#)

09-0019

Addressable Loop Powered Wall Sounder (88dBA)



[Datasheet](#)
[Addressing Guide](#)

09-0020

Input Unit



[Datasheet](#)
[Addressing Guide](#)

09-0021

Input/Output Unit



[Datasheet](#)
[Addressing Guide](#)

09-0022 Sounder Control Module



[Datasheet](#)
[Addressing Guide](#)

09-0023 Zone Monitor Module



[Datasheet](#)
[Addressing Guide](#)

09-0024 Reflective Beam - Addressable Interface Unit



[Datasheet](#)

14-0010 Conventional Reflective Beam - 5m-40m Range
Auto-Aligning with Low-Level Controller
* Requires 09-0024 Interface Unit *




[Loop](#)
[Wiring/Interface](#)
[Technical](#)
[Specification](#)
[Quick Start Guide](#)
[Range Kit Details](#)

14-0011 Conventional Reflective Beam - 40m-80m Range
Additional Kit



[Range Kit Details](#)

14-0012 Conventional Reflective Beam - 80m-100m Range
Additional Kit



[Range Kit Details](#)



We reserve the right to change product specifications without notice.
Copyright ©VRC Terofire Products 2008.